

## Proper Mailbox Installation

The face of the mailbox should be set back at a minimum of 12- 18 inches from the edge of the paved surface, or greater.

Generally, mailboxes are installed at a height of 38 to 40 inches from the road surface to the bottom of the mailbox.

